


Assembly Instructions



Installation Guidelines

- Fits poles 1.5-3.1" in diameter.
- Only for use with Araknis Outdoor WAPs
- Cable feed opening must be directed away from the open environment.
- Ensure that cable loops down and back up as it enters the connection area. (Rear or bottom cable entrance may be used.)
- Shielded Cat 5 cable or above is recommended for outdoor installation and should be grounded through the AC ground of the PoE.

Contacting Technical Support

(866) 838-5052

techsupport@araknisnetworks.com

2-Year Limited Warranty

Araknis Networks® products have a 2-Year Limited Warranty. This warranty includes parts and labor repairs on all components found to be defective in material or workmanship under normal conditions of use. This warranty shall not apply to products that have been abused, modified, or disassembled. Products to be repaired under this warranty must be returned to SnapAV or a designated service center with prior notification and an assigned return authorization (RA) number.

